



Hertz Tappeto



INFORMAZIONI TECNICHE

Tappeto Hertz

Composizione: 100% Lana Nuova Zelanda, sottofondo tela cotone.
Manutenzione: presso i centri specializzati.
Evitare l'eccessiva esposizione alla luce solare.

Manutenzione quotidiana:

Per i primi mesi e' consigliabile usare con frequenza l'aspirapolvere a media potenza per far fronte all'eventuale crearsi di lanugine. E' sconsigliato l'uso del battitappeto. Eventuali fili fuoriusciti dalla superficie vanno tagliati con le forbici, tirandoli si potrebbe rovinare il tappeto.

L'utilizzo frequente dell'aspirapolvere rimuove le particelle di sporco dalla superficie prima che si addentrino nel vello. Pulire piu' accuratamente l'area adiacente le gambe dei mobili, dove si accumula maggiormente la polvere. Del liquido accidentalmente versato sul tappeto puo' agire da calamita per lo sporco facendolo affiorare sulla superficie del tappeto provocando una macchia scura. Per la pulizia quotidiana del tappeto si consiglia l'uso di un aspirapolvere di media potenza, l'utilizzo di aspirapolvere con spazzole o battitappeto danneggia il vello. La forte azione esercitata dall'aspirapolvere estrae lo sporco accumulato tra le fibre. Eventuali fili che fuoriescono dalla superficie vanno tagliati con delle forbici. Si raccomanda di non tirare i fili. I tappeti vengono spediti arrotolati, e' quindi normale che appena aperti possano presentare grinze, pieghe o il vello schiacciato; questo effetto sparira' nel giro di qualche settimana dalla posa. Un'aspirazione leggera puo' favorire il rilassamento delle fibre.

TECHNICAL INFORMATION

Hertz carpet

Composition: 100% New Zealand wool, underlay cotton cloth.
Maintenance: at specialized centres.
Avoid excessive exposure to sunlight.

Daily Maintenance:

For the first few months it is advisable to use a Hoover at medium power frequently to deal with the possible build-up of lint. The use of a carpet beater is not recommended. Any threads sticking out of the surface should be cut with scissors; pulling them could damage the carpet.

Frequent use of the vacuum cleaner removes dirt particles from the surface before they enter in the fleece. Clean more carefully the area adjacent to the furniture legs, where dust accumulates the most. Liquid accidentally spilled on the carpet can act as a magnet for dirt making it appear on the surface of the carpet causing a dark stain. For the daily cleaning of the carpet we recommend the use of a medium power vacuum cleaner, the use of a vacuum cleaner with brushes or carpet cleaner damages the fleece. The strong action exerted by the vacuum cleaner extracts the dirt accumulated between the fibers. Any threads that protrude from the surface must be cut with scissors. It is recommended not to pull the threads. The carpets are shipped rolled up, so it is normal that as soon as they are opened they may have wrinkles, folds or a flattened fleece; this effect will disappear within a few weeks of laying. A light suction can promote relaxation of the fibers.